



Installation instructions

LP Adventure lift kit

Subaru XV Crosstrek 2018+




Necessary tools:

- We recommend the use of a lift
- Stand to support the subframe
- Ratchet
- 3" Ratchet extension
- 12mm Socket
- 14mm Socket
- 17mm Socket
- 18mm Socket
- 19mm Socket
- Key 14mm
- Key 17mm
- Key 19mm
- Long nose pliers
- Torque wrench
- Flat head Screw driver

1. Remove the wheels



2. Detach the ABS sensors



3. Unbolt the brake line bracket.



4. Unbolt the bottom and head of the suspension.

Note: Be careful, don't drop the shock on the axel.






5. Remove the front shocks



6. Install spacers on the head of the suspension




7. Install the end links and brake lines brackets




8. Reinstall the front shocks




Note:



9. Bolt the bottom of the suspension, the end links and the brake lines and ABS sensors






The rear.


Note: You must remove the carpet and plastic covers in the trunk to have access to the suspension bolts.




10. Unbolt the bottom and the top of the rear suspension



11. Install the rear top plate spacers



12. Remove the 2 plastic deflectors




13. Unbolt the brake line bracket




14. Unbolt the e-brake bracket



15. Unbolt the rear swaybar support







****** SAFETY TIPS******

**Install a crutch under the differential to hold the
subframe**

16-A. Unbolt these bolts first




16-B. Unbolt the 4 main bolts of the subframe




17. Insert the rear spacers




18. Insert the front spacers



19. Reinstall the subframe reinforcement



***** install the e-brake bracket in this way, using the spacer*****




20. Use the Z-shaped bracket to re-install the mud flaps




21. Reinstall the brake lines with the brackets



22. Bolt the sway bar spacers on the sway bar brackets



23. Reinstall the rear swaybar





24. Reinstall the rear shocks







25. Replace the bolts of the knuckle and of the suspension arm.



26. Reinstall the plastic cover and trunk carpet



27. Use the longer exhaust hangers



28. Reinstall the 2 plastic deflectors under the car

****Tighten all the bolts to the manufacturer's specifications with a Torque Wrench****

Double check your work.

Reinstall the wheels and be sure to tighten the nuts with a torque wrench.

Wheel alignment is recommended.

You have completed the installation.

Thank you for your interest in our products.

For all requests, information or assistance:

Contact our team by phone at

1 - (450) 562-0344

We are available Monday to Friday

Between 8AM and 5PM (EST).

Or by email at :

sales@lachuteperformance.com

www.lpaventure.com